


7701170
Hanging Parasol

**HOUSE
NORDIC**



FR
Pensez à
donner ou recycler.



Association

ou





Magasin

ou







Déchèterie

<https://quefairedemesdechets.fr>



MONTAGE / MONTAJE / ASSEMBLY / MONTAGEM / MONTAGGIO / MONTAGE

A		x1
B		x1
C		x1
D		x1
G		x1

H		x1
I		x1
K		x1

E



x8

F




x8


J




x1



1







2







E x8 **F** x8

3








Warnings and recommendations




Warranty: Only products used in accordance with the Manufacturer's instructions are subject to warranties and complaints.



If wind speed exceeds 6 m/sec or in heavy rain conditions, carefully remove the product, fold and secure it and put in a safe place.



Recommend to use cover, when parasol not in use.



Please empty the base after use (after season).

Dry the canvas and the frame, fold it carefully and storage the components in a dry place.